



## Ordering Guide

| <b>Rigel 80</b><br>Model | Color  | Flashing Pattern  |
|--------------------------|--|---|
| Model                    | Color  | Flashing Pattern  |
| <b>Rigel 80</b>          | <b>CA</b> - Amber<br><b>CW</b> - White<br><b>CB</b> - Blue<br><b>CR</b> - Red<br><b>CG</b> - Green<br><b>CY</b> - Yellow | <b>F0</b> – Steady<br><b>F1</b> – Flash 60<br><b>F2</b> - Flash 120<br><b>F3</b> – Fade Flash |